



Component Sheet for: KIT.RV.JLR - CMO Rivet Die Insert Kit for Jaguar / Land Rover

Total estimated weight is under 5lbs

KIT.RV.JLR 1lbs - Stand Alone Shipment

Kit 1lbs - In kit 9" x 8" x 2"

In Box Ships alone in 10" x 10" x 5"

Component Sheet for: KIT.RV.JLR - CMO Rivet Die Insert Kit for Jaguar / Land Rover

Qty:	Picture	Item No.	Description	Part Number
1		KIT.RV.JLR	KIT.RV.JLR - Jaguar Land Rover Die Kit Includes MN.JLRX, MN.W, MN.U, MN.JLRS, MN.JLRM, MN.JLRN, MN.JLRR, MN.MB8, MN.MB9	KIT.RV.JLR

Included Accessories - (Inside the kit) - Ship Weight 1 lbs

Qty:	Picture	Item No.	Description	Part Number
1		49A.14	Black Plastic Case	49A.14
1		INSERT.JLR	Insert for Jaguar / Land Rover Kit	INSERT.JLR
1		Die install and removal from arm tool	2.5 x 100mm Allen for tightening dies in arm	RV.2.5.ALLEN
1		Removing Rivets	5mm Removal Male Die for CMO Rivet Gun	MN.W
2		Pressing Rivets	Flat Die for CMO Rivet Gun	MN.U

1		Removing Rivets	Jaguar / Land Rover SPR Removal Die	MN.JLRX
1		Installing New SPR's	Jaguar / Land Rover SPR Insert Die	MN.JLRS
1		Installing New SPR's	Jaguar / Land Rover SPR Insert Die	MN.JLRM
1		Installing New SPR's	Jaguar / Land Rover SPR Insert Die	MN.JLRN
1		Installing New SPR's	Jaguar / Land Rover SPR Insert Die	MN.JLRR.2
1		Flow Form Rivet Install	Jaguar / Land Rover & Mercedes Benz Flow Form Installation Die	MN.MB9
1		Flow Form Rivet Install	Jaguar / Land Rover & Mercedes Benz Flow Form Installation Die	MN.MB8